

٠Ņ.

声明事项:

- 首先对您使用本公司的数码产品表示感谢!
- 2、在使用之前请先阅读此手册,正确使用此产品。
- 3、为了更好的服务,本使用手册的内容可能变更。 4、因产品的性能和功能而发生的变更,不做另行通知。

注意事项:

- 请勿试图打开、修复或改装本产品。
- 2、请勿将产品或其配件放入口中。
- 3、请勿将产品放入水或其他液体中。

警告事项:

- 请勿摔落产品本身或其配件,以免导致故障。
- 2、请勿让产品暴露强光或热源下,以延长本身寿命。 3、长时间不使用本产品,请将电池充满(内置锂电池)。
- 4、请勿用力拨除连接的配件(如: USB连线)。
- 5、本公司对使用本产品所造成的损失或苛刻的赔偿无 任何责任!
- 6、本公司对使用本产品或维修时所发生的资料损失不 负任何责任, 因此若在产品内, 存有重要资料, 请
 - 自行备份!
- 7、严禁将本产品用于非法用途。例如: 窃录他人隐私等!

Notifications:

- Thank you for using our company's digital products!
- 2 Please read this manual before use
- 3. The contents of this manual may be updated for better services
- 4. The product design and specification are subject to change. without notice.

Precautions:

- Do not attempt to open, repair or modify the product. 2. Do not use electronic products in the region (such as aircraft, etc.)
- to use this product.
- 3, do not put the product or its accessories into the mouth. 4. do not put the product into water or other liquids.

Warnings:

- 1, do not drop the product itself or its accessories, so as not to cause failure.
- 2, do not let the product exposed to light or heat, to extend the life of the product
- 3. please fully charge the battery (built-in lithium battery) when product under leave unused for a long time
- 4. please be careful and tenderly when connect or disconnect the earphone and USB cable.
- 5, we are not responsible for any loss and compensation while using this product.
- 6, we are not responsible for data and recordings damages during using or repairing .Please back up important data in time.
- 7, do not use for illegal purposes. For example: stealing other people's privacy!

P02

- 1: 全铝合金外壳, 外形规格8*3*1.1CM, 标准工作胸牌大小, 精致、小巧、坚固、美观、散热快
- 2: 单位名称LOGO可按需定制, 人员信息可更换
- 3:标准版、WI-FI版两种版本
- 4: 长款(显示人员信息更清晰)与短款(加强单位信息的宣传与展示)设计 5: 磁吸底座(避免重复插拔USB线让休息时充电更轻松)或内置TYPE-C接口连接电脑与充电。
- 6: 内置1550mA/H大容量锂电池满足您长时间录像的工作环境
- 7: 小巧的强磁别针、佩戴取下更方便、还可以吸附于任何铁制物体固定。 8: 视频H264+编码。


technology, completed function and stable performance and easy to carry. Easy to carry. It is widely used for on-site recording, police law enforcement records, tourist landscape shooting, sports scene shooting, etc. 1: All aluminum alloy shell, with an external specification of 8 * 3 * 1.1CM, standard working badge size,

This product can be used for live recording, video recording and photo taking. The products has advanced

- exquisite, compact, sturdy, beautiful, and fast heat dissipation
- 2: The company logo can be customized, and person information can be changed 3: Standard version and WI-FI version.
- 4: Long window (more information displayed) and short window (simple information display)
- 5: Magnetic mount (to avoid repeatedly plugging and unplugging USB cables for easier charging during breaks) or built-in TYPE-C interface to connect the computer and charging.

7: A compact strong magnetic pin that is more convenient to wear and remove, and can also be attached

- 6: Built in 1550mA/H high capacity lithium battery for long-time recording
 - to any iron object. 8: Video H264+encoding.





٠Ņ.

。开始使用:

为了正确的使用本产品、请仔细阅读说明书。

首次使用, 请充电2小时, 保证本机电量充足。 本机为全金属结构,工作或充电过程中, 出现发热情况,属于正常!


•充电:


通过USB接口或者座充可为本机充电。


充电时绿灯点亮,充满后熄灭。强烈建议:请使用 带有 (W) 标志的, 5V2A充电器为本机充电。

连接电脑:

○本机免驱动(录像时仅充电),连接电脑即可显示可移 动磁盘。







开始使用

06页

Get starting

P06

○ 开机/关机.

▶ 开机: 长按开机键3秒, 开机并开始录像, 红灯或蓝灯

(WIFI开启时)慢闪。再次短按开机键,停止并保存录 像进入待机, 待机时, 红灯或蓝灯(WIFI开启)长亮。

▶ 关机:长按开机键3秒,自动保存录像并关机。

• 电量显示: ► 开机时绿灯闪5次电量80-100%

► 开机时蓝灯闪5次电量40-80% ▶ 开机时红灯闪5次电量10-40%

▶ 电量低于40%时,每三分钟绿灯快闪10秒直至自动关机。

• 拍照 / WI-F I开关/恢复出厂设置 ▶ 拍照(仅限标准版): 开机状态下, 短按功能键拍照。 蓝灯闪亮后保存。

连接电脑后可通U盘内的DATA.txt文件查看电量

I ▶ WI-FI开关(仅限WI-FI版):开机状态下,短按功能键 打开WI-FI(蓝灯亮)或关闭WI-FI(红灯亮)。

开关WI-FI 会停止录像

▶ 待机状态下、长按功能键恢复出厂设置。

 Turn on/off Turn on: Press and hold the power button for 3

٠Ņ.

seconds to turn on and start recording, with a red

or blue light(When WIFI is turned on) Slow flashing.

Short press the power button again to stop and save the recording When entering standby mode, the red

or blue light (WIFI on) remains on for a long time. Shutdown: Press and hold the power button for 3 seconds to save the recording and shut down.

 Battery display: When turning on, the green light flashes 5 times, and the battery level is 80-100%

When turning on, the blue light flashes 5 times, and the battery level is 40-80%

When turning on, the red light flashes 5 times, and the battery level is 10-40%

minutes until it automatically shuts down.

➤ When the battery level is below 40%, the green light flashes quickly for 10 seconds every three

WI-FI switch (Wi Fi version only): When turned on, briefly press the function key Turn on WI-FI (blue light on) or turn off WI-FI (red light on).

Photo/WI-F I switch/Factory reset

Save after the blue light flashes.

Connect to the computer, you can view the battery

level through the DATA.txt file in the USB flash drive

Taking photos (standard version only): When turned

on, briefly press the function key to take photos,

Switching WI-FI will stop recording

In standby mode, long press the function key return to Factory set.

数据无价,请谨慎操作!

连接电脑后,双击打开config.bat,按屏幕提示输入

数字后按回车确认,系统设置完毕将自动同步电脑时间。

苹果客户端

▶ 手机上打开DVRunning2软件,点击去连接设备,

记录仪开机,并确认WIFI功能打开(蓝灯闪烁)

点击去连接设备

找到wifi-camera-xxxxxxxxxxx, 点击连接网络,

连接成功后返回DVRunning2软件,看到实时预览

即连接成功!

Memory card:

cancel formatting!

When turning on, the buzzer beeps continuously

for 5 times, indicating an abnormal memory card.

and the buzzer will continue after success

Three beeps. Short press the power button to

erase all files and data in the card!

System configuration file "config.bat"

synchronize the computer time. connect to a handy phone

Please select

Open in Browser

For Android OS

Short press the function key to format the memory,

Be careful, the formatting operation will

Please connect to the computer, double-click to

to input the number and press Enter to confirm.

Once the system is set, it will automatically

open "config.bat" and follow the onscreen prompts

For Mac OS

。内存卡:

开机时,蜂鸣器连续"哔"5声,为内存卡异常。

短按功能键可格式化内存, 成功后蜂鸣器连续

"哔"3声。短按开机键可取消格式化!

请注意:格式化操作将清空所有卡内文件与资料!

▶ Open the DVRunning2 software on your phone and

系统配置文件config.bat

◎ 手机连接与配网(WI-FI版):

请选在在浏览器中打开

click to connect to the device, turn on the recorder

and confirm that the WI-FI function is on


Click to connect the device

to the network after successful connection, return

to DVRunning2 software and see real-time preview

(blue light flashing)

Successfully connected!



09页


·\$

Technical data 1

P09

	技术参数
主机感光器件	1/4" CMOS传感器
别针	强磁吸附别针
照相分辨率	640*480、1280*720、1920*1080
录像分辨率	480P 720P 1080P
兼容操作系统	WINDOWS/ MAC OS/LINUX
镜头视角	145度
对焦范围	0.3米到无穷远
自动感光	支持
鼹光模式	自动曝光
照片格式	JPG(仅标准版)
视频格式	264+编码 mov格式
警号识别	可以在本机上设置使用者固定的识别码。并且每个录像文件和照片上都会自动生成使用者的识别码。
WiFi	2.4GHz~2.4835GHz IEEE802.11 a/b/g/n(标准版无WIFI)

Technical data 1					
Image Sensor	1/4 "Color CMOS sensor				
Pin	Strong magnetic adsorption pin				
Photo resolution	640*480、1280*720、1920*1080				
Video resolution	480P 720P 1080P				
os	WINDOWS/ MAC OS/LINUX				
Lens angle	Wide-angle lens 145 degrees				
Focus range	0.3 meters to infinity				
Auto light sensing	Yes				
Exposure mode	Automatic exposure				
Photo format	JPG				
Video format	mov				
User ID	Yes				
WiFi	2.4GHz~2.4835GHz IEEE802.11 a/b/g/n				



和请二 1 2 3 3 以 1 2 5 6 7 6 7 6 7 7 6 7 7 6 7 7 7 7 7 7 7 7	人保准围多日年产则(与围呆的品本障民护。:卡起免品只如保:修序机公或共法	》, 售品條件保证 保或码头 医二角大环 医乌克利氏 医电路 人名英格兰 人名英格兰人名 医克格氏管 人名英格兰人名 医克格氏管 人名英格兰人名 医克格氏管 医克氏管 医克格氏管 医克格氏管 医克格氏管	。量 、 ・ 充选 写序换修 。量 、 ・ 充选 写序换修 が 接包电择 完号の が 等く、 等 が でいます。 第一 では 第一 でも 第一 でも 第 一 でも 第 一 で 第 一 で 第 一 で 第 一 で を を 。 を を を 。 を 。 を 。 を 。 を 。 を 。 を 。 を 。 を 。 を	供一个月 观无磨损及。 \$B线、等) 务。 整或与实物 整效改。 为处理而导	
送修日期]
达修口州		1			
送修故障					
					-
送修故障					-

产			
品			
保			
修			
卡			
感谢您选购本公司数码产品			